

# HIGH RISE EQUIPMENT NEEDS

## HIGH RISE EQUIPMENT

All first alarm, non-jurisdiction companies not directed to stage or report to base will immediately report to the Incident Commander for assignment, carrying Personal Protective Equipment (PPE) for Structural Firefighting, and at a minimum, the standard equipment complement listed below, as well as any additional specialized equipment requested.

## ENGINE COMPANIES

- Stand Pipe Kit
- 3 High Rise Hose Bundles (50' sections, one with 2 ½" with 1 1/8" tip)
- Irons
- Pulling tool (rubbish hook, pike pole, or NY Rook Hook)
- Flashlight
- Fire Department communications system phone
- Building keys
- Thermal Imaging Camera (TIC)

## TRUCK COMPANIES

- Spare SCBA Bottles (at least 4)
- Blowers
- Two axes (one flat head)
- Irons
- One medium-long length pike pole
- Circular saw with fuel can
- Utility / search line
- All large hand lanterns on unit
- Fire department communications system phone
- Building keys
- Thermal Imaging Camera (TIC)

## RAPID INTERVENTION CREW (RIC) EQUIPMENT LIST

- RIC Bag
  - 1 hour bottle with regulator/mask connected with 3 foot hose
  - Emergency Breathing Support System (EBSS) manifold
  - Universal Adapter Connection (UAC) with 3 foot hose
- All large hand lanterns
- Irons
- Bolt cutter (Small)
- Channel lock pliers
- Phillips and regular head screwdriver
- Wire cutters
- Knife